

# !!!PLEASE READ!!!

## REGION CHANGING INSTRUCTIONS

### Standard DVD (see back of this sheet for codes)

Regions 0-8 (region free code) are set to automatic. Insert disc and press play

### BLUE-RAY (see back of this sheet for codes)

Regions are changed manually with remote control. To change regions:

- 1) Turn **ON** and **OPEN THE TRAY**
- 2) Once tray is completely open and not moving, press the correct region (zone) button on remote:

**Zone A:** Press YELLOW button on the remote control

**Zone B:** Press BLUE button on the remote control

**Zone C:** Press RED button on the remote control

- 3) Put your disc in the tray and close the tray

### Troubleshooting

If your disc does not play, do the following:

- Open the tray again and leave the disc in the tray
- Once fully open press the color button to select the region
- Close the tray

Be sure "**QUICK START MODE**" is in the **OFF** position

### Firmware Updates

Firmware updates can be done via the internet:

Be sure the player is connected to the internet

Go to the home menu>> setup menu>> Software Update

Click "Update Via Internet". If there is a new firmware the player will automatically update

DO NOT turn the player off while it is updating

## Standard DVD Region and Countries

- **Region code Area 0**  
Informal term meaning "playable in all regions"
- **Region code Area 1** - Bermuda, Canada, United States and U.S. territories
- **Region code Area 2** - The Middle East, Western Europe, Central Europe, Egypt, French overseas territories, Greenland, Japan, Lesotho, South Africa and Swaziland
- **Region code Area 3** - Southeast Asia, Hong Kong, Macau, South Korea and Taiwan
- **Region code Area 4** - Australasia, Central America, the Caribbean, Mexico, Oceania, South America
- **Region code Area 5** - The rest of Africa, Former Soviet Union, the Indian subcontinent, Mongolia, North Korea
- **Region code Area 6** - Mainland China
- **Region code Area 7** - Reserved for future use (found in use on protected screener copies of MPAA-related DVDs, and "mediacopies" of prereleases in Asia)
- **Region code Area 8** - International venues such as aircraft, cruise ships, etc.

## Blu-ray Region and Countries

- **Region A**: North America, South America, U.S. Territories, Japan, South Korea, Taiwan, and other areas of Southeast Asia
- **Region B**: Europe, Africa, Middle East, Australia, and New Zealand.
- **Region C**: Asia (except for Japan, Korea, Taiwan, and other areas of Southeast Asia)
- **Region FREE**: This is not an official setting, but discs that have the region FREE symbol either have no flag set or have all region flags (A, B & C) set.

**NOTE:** The region codes for commercial Blu-ray Disc movies can be found on the back of the Blu-ray Disc case.